



Industrial 16-Port Rack-Mountable USB2.0 Hub User Guide

Model : HUB-1600i-RM

Web: www.titan.tw
Support: info@titan.tw
Manual Part Number TN-074
Issue Date: 2013-06-20

Content

Introduction & Features	2
Industrial 16-Port Rack-Mountable USB2.0 Hub.....	2
Introduction of HUB-1600i-RM.....	2
Features of HUB-1600i-RM	2
System Requirements	3
Diagram of HUB-1600i-RM	3
Specifications	4
Installation	5

Introduction & Features

Industrial 16-Port Rack-Mountable USB2.0 Hub

Introduction of HUB-1600i-RM

TITAN HUB-1600i-RM is a rugged, industrial-grade 16-port USB2.0 Hub. The hub is compliant with USB2.0 specification and can expand one USB port into 16 high-efficient USB2.0 port.

The HUB-1600i-RM USB 16-Port Hub is designed for the use in industrial application under tough working environments. It is housed in a DIN-rail mountable metal case with screw holes for lockable USB and power cables. Next to each USB downstream port connector are two screw holes for lockable USB cables to add extra reliability of connection. The terminal power input connector is with two screw holes securely locking the power wires to prevent them from accidental disconnection.

The 16-port hub supports USB 2.0 full speed of 12 Mbps and USB 1.1 low speed 1.5 Mbps. It is powered by an industrial-grade switching power supply, and each downstream port provides full 500mA power to the connected USB devices. The hub incorporates the USB hub chips for industrial usage. This hub is featured with normal operation in wide ambient temperature from -40°C to 70°C operation in a harsh environment. All the USB signals are protected by 15KV ESD protection.

Features of HUB-1600i-RM

- Industrial-grade 16-port USB 2.0 Hub with rack-mountable metal case.
- Suitable for DIN-rail mounting.
- Common mode filtering on all data lines.
- Over-current detection and protection circuit design.
- Each downstream USB port supplies 5V 500mA power for external high-power USB devices.
- Individual port power management.
- Provided a terminal block connector to support 5V 1A power for external devices.
- Supports USB 1.1 and USB 2.0 transfer speeds (1.5 ~ 480Mbps), automatic link and speed detection.
- Plug-and-Play; no software or drivers required.
- 15KV ESD immunity for serial interface protected.
- LED for power and USB status indication.
- All USB connectors with screw holes for lock the USB cable.
- Supports wide ambient temperature operation -40°C to 70°C (-40°F to 158°F).
- CE, FCC approval.

System Requirements

Any PC, or Macintosh computer, with an available USB port and USB compliant operating system (Windows 8, 7, Vista, XP, 2000, ME or Mac OS 8.6 and above, etc.).

Diagram of HUB-1600i-RM



The HUB-1600i-RM provides a lockable terminal power connector to supply 5V, 1A power to each connected USB devices.



+5VDC output GND

All USB connectors with screw holes to lock the USB cable for extended security.



Specifications

The table below shows the specifications of HUB-1600i-RM

FUNCTION		SPECIFICATION
Ports	Downstream	16
	Upstream	1
LEDs	Power	1
	Port Status	16
Power Mode		Self Power Mode
Output Voltage (per port)		+5V DC
Output Current (per port)		500mA (max)
Operating Temperature		-40 °C to 70°C
Storage Temperature		-40 °C to 85°C
Humidity		0 to 90% RH. Noncondensing
Housing		Rack-mountable Metal Case
Weight		1100 g
Dimensions		427mm X 144 mm X 44mm (W x L x H) 449mm X 144 mm X 44mm (W x L x H) with ears
Input Power Range		90V AC to 264V AC
Terminal Block Connector Output Power		+5V DC 1A

Installation

This 16-port USB Hub is a plug and play device. The software driver will be installed automatically.

- 1) Connect the AC power cord to HUB-1600i-RM 16-Port USB 2.0 HUB. The red power LED will light on when HUB is receiving power. Connect the upstream port cable to an unused USB port on your computer.
- 2) After the software driver are loaded, you can find new “Generic USB Hub” in Universal Serial Bus controllers under “Device Manager” of the “System Properties” screen. (Go to “Device Manager” by selecting Start- Setting- Control Panel- System Properties- Hardware- Device- Device Manager).
- 3) Connect your USB devices to the downstream ports on the HUB-1600i-RM USB 2.0 HUB. The green USB status LED will illuminate when your USB devices connected to one of the USB ports successfully.

Copyright © 2012 TITAN Electronics Inc.
All brand names and trademarks are the property of their respective owners.

Trademarks

TITAN and the logo is a registered trademark of TITAN Electronics Inc. in Taiwan. Microsoft, Windows, Windows XP, Windows Vista, Windows Server, Windows 7, Windows 8 are trademarks of Microsoft Corporation. All other trademarks and brands are property of their respective owners.

Copyright

Copyright 2012-2014 TITAN Electronics Inc. All right reserved. Reproduction of the manual and software without permission is prohibited.

Disclaimer

TITAN Electronics Inc. provides this document and computer programs “as is” without warranty of any kind, either expressed or implied, including, but not limited to, its particular purpose. TITAN Electronics Inc. reserves the right to make improvements and changes to this user manual, or to the products, or the computer programs described in this manual, at any time.

Information provided in this manual is intended to be accurate and reliable. However, TITAN Electronics Inc. assumes no responsibility for its use, or for any infringements on the rights of third parties that may result from its use.

This product might include unintentional technical or typographical errors. Changes are periodically made to the information herein to correct such errors, and these changes are incorporated into new editions of the publication.